



## **XSORB® Rock Solid™ Paint Solidifier**

### **Instructions for Use**

1. Shake or stir XSORB Rock Solid thoroughly prior to use.
2. Amount to use:
  - For water-based paint such as latex or acrylic, add 1 cup (8 oz.) of Rock Solid to solidify approximately ½ gallon of paint.
  - For oil-based paint, add 1 cup (8 oz.) of Rock Solid to solidify one quart of paint.
3. Add to paint.
4. Stir or shake to mix. Paint will solidify in 3 to 4 minutes.
5. If the paint has not fully solidified, use additional Rock Solid.
6. Dispose in accordance with local regulations.