


SIZE CHART

EUROPEAN / AMERICAN



1, 2, 3, 4, 5 = Body measurement

SIZE CHART European / American

GARMENT SIZE USA	XS	S	M	L	XL	XXL	3XL	4XL
MENS Europe:	44	46	48-50	52-54	56-58	60-62	64-66	68-70
WOMENS Europe:	34-36	38-40	42-44	46-48	50-52	54-56		

REGULAR		C44	C46	C48	C50	C52	C54	C56	C58	C60	C62	C64	C66	C68	C70
1 CHEST WIDTH MEN	Cm	88	92	96	100	104	108	112	116	120	124	128	132	136	140
	Inches	35	36	38	39	41	43	44	46	47	49	50	52	54	55
CHEST WIDTH WOMEN	Cm	83	87	93	-	100	-	108	-	116	-	-	-	-	-
	Inches	33	34	37	-	39	-	43	-	46	-	-	-	-	-
2 WAIST WIDTH MEN	Cm	76	80	84	88	92	96	100	104	108	112	116	120	124	128
	Inches	30	31	33	35	36	38	39	41	43	44	46	47	49	50
WAIST WIDTH WOMEN	Cm	76	80	87	-	94	-	100	-	108	-	-	-	-	-
	Inches	30	31	33	-	37	-	39	-	43	-	-	-	-	-
3 HIP WIDTH MEN	Cm	94	98	102	106	110	114	118	122	126	130	134	138	142	146
	Inches	37	39	40	42	43	45	46	48	50	51	53	54	56	57
HIP WIDTH WOMEN	Cm	84	88	94	-	100	-	108	-	114	-	-	-	-	-
	Inches	33	35	37	-	39	-	43	-	45	-	-	-	-	-
4 INSIDE LEG LENGHT MEN'S GARMENT	Cm	78	80	81	82	83	84	85	86	87	88	88	88	88	88
	Inches	31	31	32	32	33	33	33	34	34	35	35	35	35	35
INSIDE LEG LENGHT WOMEN'S GARMENT	Cm	77	79	81	-	83	-	85	-	87	-	-	-	-	-
	Inches	31	31	32	-	33	-	33	-	34	-	-	-	-	-
5 BODY HEIGHT	Cm	170	176	182	182	188	188	194	194	194	194	194	194	194	194
	Inches	67	69	72	72	74	74	76	76	76	76	76	76	76	76

WASHING INSTRUCTIONS

BODYWEAR / Wash warm, no hotter than 104 degrees Fahrenheit, with a mild detergent. Hang Dry. Best to wash your synthetic clothing together (polypro's and polyesters, nylons, etc.) so lint does not build up on it during washing. Do not tumble dry or dry clean. Do not iron. Polypropylene is heat sensitive. It will survive a tumble dry on low heat, but it's best to hang dry.

PILE/FLEECE / Wash warm, no hotter than 104 degrees Fahrenheit, with mild detergent. Best to hang dry. Tumble drying puts unnecessary wear and tear on garment. Do not dry clean or iron. Best to wash your synthetic clothing together (polypro's and polyesters, nylons, etc.) so lint does not build up on it during washing.

HELLY TECH® & OTHER SHELLS / Wash warm, no hotter than 104 degrees Fahrenheit, with mild detergent. Tumble dry on medium heat for 25-30 minutes. Do not dry clean or iron. Secure all Velcro® adjustments, zip up all zippers including main zipper and adjust all draw cords to minimize ability to tangle around wash machine agitator. For best performance, keep your jacket clean and tumble dry to reactivate the DWR for improved water repellency.

PVC & PU COATED FABRICS / Wash warm, no hotter than 104 degrees Fahrenheit, with mild detergent. Hang to dry.

POLICIES

HH GUARANTEE

Since we began making performance clothing in 1877 our products have been tested in the most extreme conditions on earth. We have been on both Poles, all oceans and the highest peaks in the world. Throughout, we've stood behind every product we've made. Today that tradition remains unbroken.

If a Helly Hansen product ever fails due to a defect in materials or workmanship we will either repair it without charge or provide a replacement.

As your satisfaction is our goal, we will also endeavor to ensure our service matches your expectations.

WARRANTY RETURN POLICY

If you have questions or need to return defective product please contact the Customer Service Department at 1-866-435-5902 for a Return Authorization number. For more information on frequently asked questions regarding our warranty policy please visit our web site at www.hellyhansen.com.

Defective product should be shipped to our warehouse address:

Helly Hansen
3703 1st Street NW
Auburn, WA 98001

All returned garments must be washed prior to their return or they cannot be inspected.

Customers should enclose a note specifying the warranty problem and / or the location of the problem on the garment, as well as list specifics regarding style, color and size. The Return Authorization number should be written in large letters on the outside of the package.

The Helly Hansen Warranty Department will inspect the product at no charge to you. If the Warranty Department determines, in its sole discretion, that the product has a defect covered under this Warranty, we will repair or replace it within approximately four weeks. If the defective garment is not repairable and an identical product is not available, we will replace it with a garment of comparable style and color at our discretion.

NOTE

Return authorizations not received within 30 days of issuance will be void and cancelled. Products purchased as irregulars/discontinued will not be authorized for return.

ORDER DISCREPANCIES

Discovery of discrepancies on your order must be reported to Helly Hansen Customer Service within 30 days of invoice date. All requests must be accompanied by complete invoice numbers. A request received after 30 days will not be accepted.

DAMAGED SHIPMENTS

Inspect all shipments carefully. Verify the total number of cartons and check for exterior carton damage. All claims for lost or damaged shipments must be made directly to the delivery carrier. Helly Hansen is not responsible for damage during shipment.