



Wall Mount Hose Reel Model #703 Instructions

Tools required: one adjustable wrench

1. Remove the flange nut holding the black handle to the steel crank.
2. Reverse the handle and re-attach using the same flange nut. Tighten securely. If desired, the two nuts may be adjusted to allow the handle to rotate freely.

PERMANENT WALL MOUNTING:

No mounting hardware is provided with the unit. There are too many different surfaces that the unit could be mounted on. When mounting, remember that the unit with a water filled hose could weigh as much as 35 pounds. Mount the unit securely to a solid surface. Ensure that large, long steel hardware is used.

TEMPORARY WALL MOUNT:

No mounting hardware is provided with the unit. However, the unit may be secured to a wall using hooks in the top mounting holes and two bumpers (feet) in the bottom mounting holes. This way the unit may be easily removed from the wall for winter storage. Please remember that the water filled unit could weigh as much as 35 pounds and must be mounted to a solid surface with large, long steel hardware.




Figure 1

FLOOR STANDING UNIT:

Insert the four bumpers (feet) provided into the mounting holes on the base of the unit. Lubricating the bumpers with water or a light lubricant will ease the insertion.

GROUND MOUNTING:

Use the four stakes provided to secure the unit to the lawn or earth. Place the stakes through the holes in the base.

ATTACHING THE HOSE:

1. Attach the leader hose to the end of the swivel. **DO NOT OVER TIGHTEN!** Attach the other end of the leader hose to the water supply.
2. Attach your garden hose to the brass adapter. Loop over the spool end (Fig 2) to avoid kinking.

NOTE: It is normal for the hose connections or the swivel to leak initially until the washer and o-rings have become wet and seated. This may also occur if the reel has not been used for a long time and the o-rings have dried out.

RECOMMENDATION: To help delay rust, repaint any parts of the unit from which paint has been scraped. Use a weatherproof paint to seal fasteners (bolts, wing nuts). If the unit is exposed to lawn fertilizer, thoroughly rinse the entire unit. Fertilizer will damage the unit's finish if not removed.




Figure 2

Questions? Please contact us at:
www.libertygardenproducts.com

